

**REAR-AXLE SLIDERS ADAPTABLE TO:
BMW F800R'15-**

REF: 8603N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the left side.
- 3) Mount the slider (1), fastening the set with the washer (4) and nut (5).

Material supplied:

POSICIÓN	DENOMINACIÓN	CANTIDAD
1	Right Slider	1
2	Left Slider	1
3	Rod	1
4	M6 washers DIN125	2
5	M6 nut DIN985	2
6	Caps with color rings Blue-Red-Gold-Silver	8

