

**FRONT-AXLE SLIDERS ADAPTABLE TO:
SUZUKI VSTROM 1000 '14-16'**

REF: 8672N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (2), place the rod (3) through the axle from the left side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

| POSICIÓN | DENOMINACIÓN | CANTIDAD |
|----------|---|----------|
| 1 | Right Slider | 1 |
| 2 | Left Slider | 1 |
| 3 | Rod | 1 |
| 4 | M6 nut DIN985 | 2 |
| 5 | M6 washers DIN125 | 2 |
| 6 | Caps with color rings Blue-Red-Gold-Silver | 8 |

