

**REAR-AXLE SLIDERS ADAPTABLE TO:
SUZUKI VSTROM 1000 '14-**



REF: 8673N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the other slider (1), place the rod (3) through the axle from the left side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

POSITION	DENOMINATION		AMOUNT
1	Protector derecho	<i>Right Slider</i>	1
2	Protector izquierdo	<i>Left Slider</i>	1
3	Varilla	<i>Rod</i>	1
4	Tuerca M6 DIN985	<i>M6 nut DIN985</i>	2
5	Arandelas M6 DIN125	<i>M6 washers DIN125</i>	2
6	Tapones con aros de color Azul-Rojo-Oro-Plata	<i>Caps with color rings Blue-Red-Gold-Silver</i>	8

