

**FRONT-AXLE SLIDERS ADAPTABLE TO:
TRIUMPH STREET TWIN '16**

REF: 9158N

MOUNTING INSTRUCTIONS

- 1) Remove the slider (1) from the set supplied.
- 2) Without removing the her slider (2), place the rod (3) through the axle from the right side.
- 3) Mount the slider (1), fastening the set with the washer (5) and nut (4).

Material supplied:

POSICIÓN	DENOMINACIÓN	CANTIDAD
1	Left Slider	1
2	Right Slider	1
3	Rod	1
4	M6 nut DIN985	2
5	M6 washers DIN125	2
6	Caps with color rings Blue-Red-Gold-Silver	8

TIGHTEN NUT M6 WITH A TORQUE OF 9,7Nm

