

INSTRUCTIONS TO ASSEMBLE

Remove the fasteners that subject the chassis to the engine, on the point marked below (and the opposite side). Mount the protectors on each own side as the figure below shows.

Tight the set, and place the caps.

All the screws replaced, should be tightened to the torque specified in the oem maintenance manual for your motorcycle. if no torque specifications are provided in the oem maintenance manual, may be used 54Nm for all M10 screws.

Medium strength liquid thread-locker (i.e., "Loctite") should be used to secure all screws, bolts and nuts.

All screws, bolts and nuts should be checked after driving the first 50 km to ensure that all are tightened to the proper torque.

ID.	DESCRIPTION	REF.	QTY.
1	Plastic cap	CONGOMANPRO-R12	2
2	M10/150x40 DIN912 screw	TORNIAD912-0370	2
3	M10 DIN125/A washer	M2AM10DINI25AZB	2
4	Nylon protector 50mm	PROTECNCR12-145	2
5	Aluminium spacer (silver color)	CASQU409-0-1709	2
6	Right aluminium spacer 92 mm (black color)	CASQU354-0-1654	1
7	Left aluminium spacer 97 mm (black color)	CASQU350-0-1650	1
8	Ø12x242 bar	VARILL13-I-1446	1

FOR TO ASSEMBLE THE CRASH PADS, IF YOU ARE NOT A TRAINED MECHANIC, PLEASE CONTACT A SPECIALIST. MOTOPLASTIC, S.A. TAKES NO RESPONSIBILITY FOR DAMAGES CAUSED BY IMPROPER INSTALLATION. THE USE OF CRASH PADS DO NOT GUARANTEE A FULL PROTECTION IN CASE OF ACCIDENT. MOTOPLASTIC-PUIG DECLINE ANY RESPONSIBILITY IN CASE OF MOTORCYCLE DAMAGE.

MOUNTING INSTRUCTIONS

CRASH PADS FOR

DUCATI MONSTER 797 '17-

Ref.: 9497N



