PUTCO
Security Kit Installation Instructions

Congratulations on your purchase of a high quality PUTCO product.

Please read all instructions before installation and to check to see that all parts are included.

KIT CONTENTS:	
Description	**Qty.**
Installation Tool	1
Security Nuts	2

Tools Needed:
- 1/4" Wrench or Socket Wrench

Security Kit Installation

1. Remove parts from packaging. Check to see if all parts from above table are included.

2. Remove vinyl caps and Nylock nuts if already installed (Save for optional step). If light bar has not been installed previously refer to light bar instructions up to this point.

3. Thread on security nuts by hand with tapered end (small side) facing out.

4. Align installation tool with three holes on security nut. Using a 1/4" wrench/socket wrench, tighten nut until light bar can not be rotated easily.

5. Periodically Check tightness and re-torque as necessary

6. **Optional:** Re-install Nylock nuts and vinyl caps

Choose reliable off-road lights offered on our website.