



FITTING INSTRUCTIONS FOR R&G CARBON/KEVLAR ENGINE CASE SLIDERS



- Ensure the bike's engine casings are cold and that the bike is properly supported.
- Thoroughly clean the engine casing(s) to which you are going to apply the Engine Case Slider.
- Wash off any residue from cleaning agents used
- Allow to dry fully
- Apply Silicone provided to the Engine Case Slider equally across all areas.
- Place Engine Case Slider onto the engine casing and leave to dry for at least thirty minutes.
- Do not attempt to "test" the adhesion, by pulling at the Engine Case Slider, for at least thirty minutes after fitting.
- Test adhesion by giving a reasonable tug on the Engine Case Slider.
- Removal is possible but should require extreme pressure to achieve.