



**FITTING INSTRUCTIONS FOR FI0009BK FRAME INSERTS  
KAWASAKI ZX10 '08- (LEFT HAND SIDE ONLY)**



**Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike**

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

**Left-hand side (as you sit on bike)**

- Fit button head bolt through frame insert so head sits in counter-bore.
- Place special nut on exposed end of bolt so tapered face goes into tapered counter-bore.
- Tighten bolt until tapered portion of nut just contacts tapered face of plastic frame insert.
- Place the assembly into spindle in position shown above with recess horizontal as shown above.
- Tighten bolt so frame insert is held in position firmly (do not over tighten).
- Place bubble sticker as shown above.
- Regularly check to ensure frame insert remains tight.