



FITTING INSTRUCTIONS FOR FI0139BK FRAME INSERT
DUCATI PANIGALE V4, V4S & SPECIALE '18- SWINGARM PIVOT BOTH
SIDES



THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt –
the rubber washers should be thrown away!

TOOLS REQUIRED

- 4mm metric Allen key.

FITTING INSTRUCTIONS

- Fit countersunk bolt through frame insert so head sits in counter-bore.
- Place special nut on exposed end of bolt so tapered face goes into tapered slot.
- Tighten bolt until tapered portion of nut just contacts tapered face of metal frame insert.
- Place the assembly into swingarm pivot recess in position as shown above.
- Tighten bolt so frame insert is held in position firmly (do not over tighten).
- Regularly check to ensure frame insert remains tight.
- This fits on both sides of the bike.