



MOUNTING SUGGESTIONS:

Harley-Davidson® Dyna 2006-2016 Solo and Passenger Seats

Hardware (Included):	Solo: Fender nut kit	Passenger seat: 1/4"-20 x 1" buttonhead Allen bolt Slotted spool washer
Tools needed:	Phillips screwdriver 5/32" Allen wrench	

Removal of stock

seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips

screwdriver and set it aside. The stock

rear fender screw will be used to attach your new Revere seat.

2. Remove the handstrap if present.

3. Slide the seat up and back to disengage the front bracket and remove the seat.

4. Remove any rubber bumpers or handstrap bolts from the fender. These are not needed to mount your Revere seat.



Installation of Revere seat:

Solo:

1. If center mount near front of rear fender is plugged, remove plug and install supplied fender nut.
2. Insert nose tab into frame mount under tank.
3. Align rear bracket with fender nut. If installing solo alone, secure the bracket to the fender with the stock screw. If installing a passenger seat, secure to the fender with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer.



Passenger seat:

1. Remove the stock screw mounting the back of the solo and replace with the supplied $\frac{1}{4}$ "-20 x 1" buttonhead bolt and slotted spool washer. The slotted washer should sit directly on top of the solo bracket.
2. Align slot at front of passenger seat with the slotted spool washer mounted above the solo seat's rear bracket, and slide the seat forward to engage the washer.
3. Align rear bracket with rear mount in fender and secure with stock screw.

Enjoy the comfort and custom look of your new Revere seat!

