



MOUNTING SUGGESTIONS:

Harley-Davidson® Dyna 2006-2017 One-piece Seat

Hardware:	Stock fender screw
Tools needed:	Phillips screwdriver

Removal of stock seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Revere seat.
2. Remove the handstrap if present.
3. Slide the seat up and back to disengage the front bracket and remove the seat.
4. Remove any rubber bumpers or handstrap bolts from the fender. These are not needed to mount your Revere seat.



Installation of Revere seat:

1. Insert nose tab into frame mount under tank.
2. Align rear bracket with fender nut and secure the bracket to the fender with the stock screw.

Enjoy the comfort and custom look of your new Revere seat!



These steps are guidelines to help you install your new Revere product.