



## MOUNTING SUGGESTIONS:

### Harley-Davidson® FL Touring 2008-2018 One-piece Seat

**Hardware:** Stock 1/4"-20 x 1/2" rear fender screw

**Tools needed:** Phillips screwdriver

#### Removal of Stock Seat:

##### *Two-piece stock seat:*

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Revere seat.

2. Slide the rear seat back and up.

3. Remove the two nuts holding the solo in place.

4. Carefully lift the back of the driver's seat up and back to disengage the front bracket and remove the seat.



##### *One-piece stock seat:*

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw will be used to attach your new Revere seat.

2. Remove hand strap that is secured to the motorcycle on each side of the seat where the front saddlebag mount is located.

3. Slide the seat up and back to disengage the front bracket and remove the seat.

## **Installation of Revere Seat:**

1. Remove any seat supports from the frame rails and be sure wiring is routed along the inside of the frame rails. CVO models: Remove any plastic trim from the fender so the Revere seat installs on the bare fender.
2. If the seat is heated, connect the cable to the accessory port. Be sure port is free of dirt and debris. If the accessory port is already in use, use Harley® part 70264-94A or 70270-04 to add additional ports. Check to be sure there are no folds or kinks in the wire before installing seat.

**Note: Installation of heated seats on 2014-up FL Touring motorcycles requires use of Harley® adaptor 69200722 or 69201599, depending on the year.**

3. Engage the nose bracket into the frame.
4. A firm downward punch or chop to the nose of the seat will push the seat closer to the chrome dash. If there is a gap at the dash, the dash can be adjusted by loosening the  $\frac{1}{2}$ " hex nut and Phillips screw on the dash, sliding the dash back and retightening.
5. The seat is spring-loaded, so the rear mounting bracket will be approximately 1" to 1-1/2" above the fender mount. Gently push seat down and secure to fender with stock screw.
6. Revere suggests that a rack-mounted backrest be set to the rearmost position. Fully loosen the four nuts under the outer rack channels and tap the backrest rearward to the end of the slots, and retighten the nuts.

## **Using a Backrest:**

1. Using a backrest with seats with a split in the baseplate between the rider and passenger seats requires first mounting a Harley® or Revere frame-mounted backrest kit. The post on the Revere kit is bent to account for the angle. It may be necessary to add washers as spacers to the front mount to refine the angle.
2. Seats without a split in the baseplate but with a split in the cover use a straight-post Revere backrest. A bent-post backrest from a frame-mounted backrest kit will not work with these seats.

**Enjoy the comfort and custom look of your new Revere seat!**

