



MOUNTING SUGGESTIONS:

Harley-Davidson® FL Touring 2008-2016 Revere Solo Seat

Hardware (Included):	Acorn nut x 2 Black nylon shoulder washer x 2 Chrome washer x 2 Small retaining washer x 2
Tools needed:	Phillips screwdriver 7/16" open-end wrench

Removal of Stock Seat:

Two-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver.
2. Slide the rear seat back and up.
3. Remove the two nuts holding the solo in place.
4. Carefully lift the back of the driver's seat up and back to disengage the front bracket and remove the seat.



One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver.
2. Remove hand strap that is secured to the motorcycle on each side of the seat where the front saddlebag mount is located.
3. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Revere Seat:

1. Remove any seat supports from the frame rails and be sure wiring is routed along the inside of the frame rails.
2. Remove one of the large retaining washers from the stud plate in the front of the fender and replace with the supplied smaller retaining washer. **Do not remove both retaining washers at the same time.**
3. Repeat process with the other retaining washer.
4. Engage the nose bracket into the frame. Push it as far forward as possible so that the mounting studs in the fender are in the middle to back edge of the slotted rear tabs.
5. A firm downward punch or chop to the nose of the seat will push the seat closer to the chrome dash. If there is a gap at the dash, the dash can sometimes be adjusted by loosening the $\frac{1}{2}$ " hex nut and Phillips screw on the dash, sliding the dash back and retightening.
6. The seat is spring-loaded, so the rear mounting bracket will be approximately 1" to 1-1/2" above the fender mounts.



5. Place the nylon shoulder washers on the fender studs and then put the rear mounting tabs over the studs.

6. Place the chrome washers over the studs and secure the seat with the acorn nuts. Tighten both finger-tight, then tighten both securely.

Enjoy the comfort and custom look of your new Revere seat!

