



MOUNTING SUGGESTIONS:

Harley-Davidson® Softail 2000-2015 Revere One-piece Seat

Hardware:	Stock fender screw Stock rear bracket or Revere part 78037 (<i>not included</i>) or Revere part 78116 (<i>included</i>)
------------------	---

Tools needed:	Phillips screwdriver 7/16" wrench or nutdriver
----------------------	---

These seats will install on the following motorcycles. If your motorcycle is not listed, please contact Revere for fitment.

- FLSTF Fat Boy 2000-2006* and FLSTFSE 2005*
- FXST Softail 2000-2005*
- FXSTB Night Train 2000-2005*
- FXSTS Springer 2000-2005*
- FLST Heritage 2006*
- FLSTC Heritage Classic 2000-2006*
- FLSTC Heritage Classic 2007-2015†
- FLSTS Heritage Springer 2000-2003†
- FLSTSC Heritage Springer Classic 2005-2007†
- FLSTN Deluxe 2005-2015† - **must remove standard rack**

Installation of Revere seat:

1. For models listed above with a star (*), transfer the rear bracket from the stock seat to the Revere seat with the provided hex bolts, or use Revere part 78037.
2. For models listed above with a dagger (†), mount the provided rear bracket to rear of Revere seat.
2. Insert welded nose tab into frame mount under tank.
3. Align rear bracket with fender nut and secure the bracket to the fender with the stock screw.

Note: The angles of the steel pan may need to be adjusted slightly to fit your specific bike.

Enjoy the comfort and custom look of your new Revere seat!



These steps are guidelines to help you install your new Revere product.