



MOUNTING SUGGESTIONS:

Harley-Davidson® Sportster 2004-2018 One-piece Seat

Hardware:	Stock fender screw
Tools needed:	Phillips screwdriver

Note: Certain Revere seats will not install on 2007-2009 Sportsters or models with specific fuel tanks. Please be sure your seat is correct for your year and tank size.

Removal of stock seat:

One-piece stock seat:

1. Remove the rear 1/4"-20 fender screw with a Phillips screwdriver and set it aside. The stock rear fender screw



will be used to attach your new Revere seat.

2. Remove the handstrap if present.
3. Slide the seat up and back to disengage the front bracket and remove the seat.

Installation of Revere seat:

1. Insert nose tab into frame mount under tank.
2. Align rear bracket with fender nut and secure the bracket to the fender with the stock screw.

Note: The shoulder bolt on the frame is not needed to mount the Revere seat. A hole in the baseplate will accommodate the bolt. Flex the fiberglass pan when installing to ease the hole around the bolt.

Enjoy the comfort and custom look of your new Revere seat!



These steps are guidelines to help you install your new Revere product.