



Fitting Instructions for RAD0149BK Radiator Guard
DUCATI HYPERMOTARD/HYPERSTRADA 821 2013



In This Kit There Should Be
1x Radiator Guard (RAD0149BK)
1x Cable Tie
2x 100mm Lengths of self-adhesive Foam



Picture 1



Picture 2



Picture 3



Picture 4



Picture 5



Picture 6

TOOLS REQUIRED

- Socket set to include 3 & 4mm socket & wrench.
 - Cutters.

FITTING INSTRUCTIONS

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.
- Remove three bolts that secure the inner black plastic panel in place on the side pods on both sides of the bike, as shown in picture 1. This will then allow the panels to be gently pulled clear to allow easier access to the radiator mounting bolts.
- Remove the bolts that secure the top of the radiator in place on both sides of the bike, as shown in picture 2.



- On the bottom of the radiator, gently push the metal boss out of the rubber mount by 5mm. this will allow the lower mounting bracket on the R&G Radiator Guard to slot over the metal boss, as shown in pictures 3 & 4.
- Offer the R&G Radiator Guard into position. This will need to be gently slid down onto the lower boss and then the two top brackets will align with the top radiator mounts. Re-fit the original bolts on both sides and tighten, as shown in picture 5.
- In the bottom right corner of the radiator guard, feed the cable tie through one of the slots, then through the corner of the radiator matrix, before looping back on itself and reconnecting through the second slot, then gently tighten.
- Refit the bolts that secure inner plastic panels in place.
- Ensure all bolts are tightened evenly and the radiator is correctly mounted.