



Fitting Instructions for RAD0158BK Radiator Guard
SUZUKI BANDIT GSF1250S & N '07-



In This Kit There Should Be
1x Radiator Guard (RAD0158BK)
1x M6x 25mm Long Button Head Bolt
2x M6x 35mm Long Button Head Bolts
3x M6 Washers
2x 100mm Lengths of self-adhesive Foam



Picture 1



Picture 2



Picture 3



Picture 4

TOOLS REQUIRED

- Socket set to include 4mm A/F & 10mm socket & wrench.

FITTING INSTRUCTIONS

- To fit the radiator guard to the bike cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.
- Remove the bolt that secures the bottom of the radiator in place, as shown in picture 1.
- Remove the two bolts that secure the two top mounts of the radiator in place, as shown in picture 2.
- Offer the R&G Radiator Guard into place on the bike, ensuring that the brackets on the top of the radiator guard located on the rubber mounts at the top of the radiator, before fitting the two M6 x 35mm long button head bolts provided with washers on through the radiator guard and into the frame mounts, as shown in picture 3.
- On the bottom mount, locate the remaining M6 x 25mm long button head bolt through the remaining washer, then through the lower mount of the radiator guard and into the threaded radiator boss, before tightening, as shown in picture 4.
- Ensure the radiator guard is correctly mounted and tighten all bolts evenly.