



**Fitting Instructions for RAD0164 BK/OR Radiator Guard**  
**KTM 390 DUKE 2013**



**In This Kit There Should Be**  
**1x Radiator Guard (RAD0164BK/OR)**  
**4 x Cable/Zip Tie**  
**2x 100mm Lengths of self adhesive Foam**

- To fit the radiator guard to the bike, cut the foam strip provided into 10mm wide pieces and stick them to the back of the radiator guard frame, so that they sit between the radiator guard and the radiator.

**Fitting Instructions**

- Undo and remove the 2 retaining nuts on the upper mounting points above the Radiator  
(Arrow #1 on pic)
  - Leave the spring washers in place on the protruding studs
- Undo and remove the 2 retaining nuts & spring washers on the lower mounting points below the radiator (Arrow #2 on pic)
  - Fit the radiator guard into place locating on the 4 protruding studs
    - Tighten all 4 nuts to secure the radiator guard
- The spring washers will be underneath the radiator guard on the upper mounting points, and on top of the radiator guard on the lower mounting points



Learn more about motorcycle starting and charging parts on our website.