



**FITTING INSTRUCTIONS FOR KTM SWINGARM PROTECTORS
(CODE SP0002BK)**

PLEASE NOTE THAT THE WAY THE KIT IS PACKED DOES NOT NECESSARILY REPRESENT THE WAY OF MOUNTING TO THE BIKE

- Undo rear wheel spindle nut and remove
- On the side where the nut was, slide steel bar through the hollow spindle (and knock out plastic insert at other end of spindle), so that the end with the shorter (LC4 model) or longer (SMR / EXC models) shoulder is to the chain side of the bike
- Replace nut with the item supplied in the pack (tighten to 59 lb / ft torque)
- Place bobbins at either end of spindle, ensuring that the nut is covered (bobbin with the deeper recess covers the nut)
- Place washers onto ends of bar
- Secure nyloc nuts in place. Just tighten them until they lock – do not overtighten.