



**FITTING INSTRUCTIONS FOR SP0007BK SWINGARM PROTECTORS
SUZUKI DRZ 400**

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

- Fit one nut to end of the spindle bar in the kit
- Slide washer up behind the nut
- Slide one of the protectors up behind the washer
- Push assembly through the hollow spindle (if protector will not locate properly, insert assembly from the opposite side)
- Place other protector over exposed end of spindle bar
- Fit washer and nut to end of spindle bar
- With a socket on either end, tighten until the assembly locks into place
- Do not overtighten – the nyloc nuts will hold it tight.