



**FITTING INSTRUCTIONS FOR SP0022BK SWINGARM PROTECTORS
KTM 690 DUKE III '08-, 690 ENDURO '08-, 690 SM & 690 SMC '08-**



Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

- UNDO AND REMOVE REAR SPINDLE NUT ON RIGHT HAND SIDE AND REPLACE AND TIGHTEN WITH NEW NUT FROM KIT.
- SLIDE SPINDLE BAR THROUGH THE NEW NUT AND REAR SPINDLE.
- PLACE THE FLAT SPACER ON SPINDLE BAR SO IT SITS AGAINST NEW NUT.
- PLACE THE STEPPED SPACER OVER SPINDLE BAR AND INTO SPINDLE ON THE LEFT-HAND SIDE.
- PLACE BOBBINS OVER BOTH ENDS OF SPINDLE BAR.
- SLIDE A WASHER (PLEASE NOTE ON 690 ENDURO 2008 YOU WILL NEED TO USE 2 WASHERS PER SIDE) AND NUT OVER BAR AT EACH END AND TIGHTEN. **DO NOT OVERTIGHTEN – THE NYLOC NUTS WILL HOLD IT TIGHT**