



INSTALLATION INSTRUCTIONS

IGNITE MOTORCYCLE KIT

Always disconnect any power sources connected to your vehicle before servicing fuses or electrical systems. Professional installation is recommended.

Note: When selecting light location, consider wire routing and range of motion of front wheel. If a fork or freeway bar mount location is desired.

1. Mark and drill holes for install, use 1/4" drill bit
2. Install lights using provided hardware.
3. Select switch location, mount using provided radius mount pad and zip ties, or double sided adhesive tape.
4. Wiring: Route wire leads, switch wire leads and harness. Trim excess wire, secure to bike using zip ties. Take care to avoid any heat sources & sharp or abrasive surfaces.
5. Reconnect power source, point bike at wall to aim lights. To toggle between high and low modes, turn the switch off and on quickly (within 3 seconds).