

## HD060

### **FLH removable Tie-Down Brackets**

1. Remove the Acorn nuts from the right side of the steering head or forks. Install two of the supplied retaining nuts and tighten securely.
2. Install the nuts on the left side in the same manner.
3. When trailering the bike place the keyhole slots in the brackets over the retaining nuts (2A) and slide them downwards. Place the hooks of your tie downs thru the slots in the bracket (2B).
4. Be sure to remove the brackets after trailering the bike as they are not intended to be on the bike while riding.

We recommend placing the ratcheting or buckle end of the tie down at the bottom or the floor of your trailer as shown. This will help prevent any damage to the bike from the ratchet or buckles.



