

Installation instructions for

LED-7443

Tail/Flashing brake light LED bulb conversion

For all 2001 and newer Honda Gold Wing 1800

1. Remove both tail lights from the trunk as follows. Inside the trunk locate the three 8mm acorn nuts in the corners of the trunk that secure the lights to the trunk and remove them. Pull the tail lights out from the trunk to gain access to the bulb sockets and wires. Twist the bulb sockets counterclockwise (as facing the socket) about 30 degrees until they stop then remove the socket with wires from the lens assembly. Set the lenses aside.
2. Remove the bulbs from their sockets by pulling them outward. The new LED bulbs are polarity sensitive, install them as follows. Turn the ignition switch on. Plug one of the bulbs into one of the inner, closer to the center, of the trunk sockets (has 3 wires and a white wire plug). If the bulb does not light remove it (be careful and grab the bulb at it's base when pulling them out so as not to damage the LEDs), rotate the bulb 180 degrees and plug it in again, it should now be on. Repeat this on the other socket with 3 wires and a white plug.
3. With the ignition still on place one of the remaining bulbs into one of the sockets. Depress the brake pedal or lever, this LED should come on and flash, if not reverse the bulb and try it again. Repeat this with the remaining bulb and socket.
4. With the ignition still on verify that the inner LEDs are on and all four come on and flash when the brake lever or pedal is depressed
5. Reinstall the bulb/sockets into the lenses being sure the sockets with the wires and the white plugs are in the inner/toward center holes of the lenses. Reinstall the lens assemblies into the trunk.