

Lower Leg Fairings For 1995 & Newer Harley-Davidson FLH models, except Road Glide *(Note: Does not fit Deluxe models)*
#MV100

1. Layout and familiarize yourself with the lowers and the supplied hardware.
2. Locate the "P" clamps. Open the clamps using a screwdriver and or pliers. Slide the clamps over the bottom of the crash bars, about 6" from where they bolt to the bike with the flat side of the clamp facing up, and both tabs facing towards the rear. Using pliers, close the clamps, but leave a 3/8" gap.
3. Unsnap and remove the covers from the storage compartments. Remove the two 10mm bolts inside the compartment which secure the front covers to the lowers - and then remove the upper front facing covers.
4. Place the lowers up onto the crash bars, working them in from the tip and behind the crash bars. Place the upper front cover over the front of the crash bars and seat them in place on the main part of the lowers. Start the two 10mm bolts removed earlier.
5. Use the remaining supplied hardware in the bottom holes of the lowers and through the "P" clamp as follows: Place a flat washer onto the bolts. Next - place the bolt with washers from the top down through the lowers, then place the rubber washer onto the bolt. Put the bolt through the holes in the "P" clamps followed by another flat washer and the locking nuts.
6. Align the lowers to fit up against the crash bars uniformly and snugly on both sides. Then tighten the upper 10mm bolts, and the lower 1/4" bolts and nuts (Note: Do not over- tighten the lower bolts - they only have to close the "P" clamp and compress the rubber washer slightly).

