



3" PEG EXTENSIONS
INSTALLATION INSTRUCTIONS
#PEGSEXT

- ❖ Remove the foot peg from the folding clevis base by loosening the allen bolt at the end of the foot peg, then remove the allen bolt from the peg.
- ❖ Place the new longer allen bolt thru the peg and slide the smaller, male end of the peg extension onto the bolt.
- ❖ Screw this assembly back into the clevis or folding part of the peg base.
- ❖ Rotate the peg to the desired angle and tighten the allen bolt.

Rely only on high-grade motorcycle foot controls & pegs offered on our virtual shelves.