

VCC007-50
Trailer Wiring CAN-bus Module
For Indian Models
Installation Instructions

The VCC007-50 CAN-bus Module provides the correct signal to your isolator from the Indian wiring. Indian Motorcycles are not designed to power the lights directly.

YOU MUST ALSO USE RIVCO isolator TWC003, and RIVCO sub-harness VCC007-49

1. Once you have installed our sub harness VCC007-49, Plug the VCC007-50 CAN-bus Module into the 4 prong square plug.
2. Plug in the TWC003 five-to-four wire converter into the VCC007-50 CAN-bus Module.

When it comes to quality motorcycle towing products & accessories, Rivco is the brand you can depend on.