



ROLAND SANDS DESIGN®

ASSEMBLY INSTRUCTIONS

RSD BELT GUARD



PRODUCT DESCRIPTION

RSD BELT GUARD ASSEMBLY : 2004 AND UP XL SPORTSTER (EXCEPT XRI200R)

0217-2006

RSD BELT GUARD INSTALLATION

1. Turn your motorcycle off, place securely on a lift or side stand.
2. Remove the factory sprocket cover. **Note:** Some components such as exhaust and brackets may need to be removed, Consult your HD service manual for specific instructions.
3. Use medium strength thread locker on the supplied 1/4-20 and 3/8-16 socket head bolts.



4. Install the RSD Belt guard using the supplied spacers. Torque the 3/8-16 bolt to 30-33 ft-lbs and the 1/4-20 bolt to 80-120 in-lbs.



5. Reinstall any components that were removed. Install the RSD countershaft pulley cover 0217-2007 (Sold separately) to complete the tracker look.
6. Hit the road.