



## RSD UPPER FORK TUBE COVER



## RSD UPPER FORK TUBE COVER INSTALLATION

1. Turn your motorcycle off, place securely on a lift or center stand and disconnect the battery.
2. Begin by removing the seat and fuel tank.  
**NOTE:** Consult your HD service manual for specific instructions.
3. Loosen the two pinch bolts and center stem on the top clamp. Remove the clamp.



4. Install the first o-ring on to the fork leg then the RSD fork tube cover and the last o-ring after. Repeat on other side.

**NOTE:** Place the side with the part number facing downward.



5. Install the top clamp and center stem. Tighten both pinch bolts.  
**NOTE:** Consult your HD service manual for specific instructions to reinstall top clamp and center stem.
6. Install any other components removed during installation.



7. Hit the road!

### PRODUCT DESCRIPTION

39mm CHRONO	0208-0115M	39mm CHRONO XLI200	0208-0130M
39mm SMOOTHIE	0208-0116M	39mm SMOOTHIE XLI200	0208-0131M
39mm TRACKER	0208-0117M	39mm TRACKER XLI200	0208-0132M
41mm CHRONO	0208-0118M	49mm CHRONO	0208-0121M
41mm SMOOTHIE	0208-0119M	49mm SMOOTHIE	0208-0122M
41mm TRACKER	0208-0120M	49mm TRACKER	0208-0123M