


## **KEEWAY VIESTE 125 '20**









**2** 303017 x6 Ø6



**3** 304079 x2 M6 x 30 Din 7380



**4** 303020 x4



**5** 304272 x4 M8 x 35 Din 7380

## **WARNING!**



Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

