


# SHAD

## SUZUKI BURGMAN 400 '17

### KIT TOPMASTER SOBR47ST




1 262205 x1



2 261502 x2  
Ø16 Ø9 x 42



3 303025 x2  
Ø10




4 304236 x2  
M8 x 65 Din 7991



5 261265 x2  
Ø16 Ø9 x 53



6 303045 x2  
Ø8



7 304174 x2  
M8 x 80 Din 7380

### ! WARNING!

GB

To complete the set, remember to purchase the backrest with your preferred color. Do not fully tighten. Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

