


SHAD

BMW F800 R/S '09-
WOFR89iF



- | | | | | | |
|---|---|---|--|--|---|
|  1 304166 x2 M8 x 50 DIN 7380 |  2 261711 x1 → 261712 x1 ← |  3 202478 x2 |  4 261672 x4 Ø18 Ø12 Ø7 x 7,5-2 |  5 304057 x4 M6 x 25 DIN 912 |  6 303000 x4 Ø6 |
|  7 303020 x6 Ø8 |  8 304036 x4 M8 x 45 DIN 7380 |  9 260648 x2 Ø16 Ø9 x 5 |  10 303045 x 2 Ø8 |  11 302024 x2 M8 | |

! WARNING!

GB

Do not fully tighten
the screws until it is
ensured that the KIT
is correctly attached
and aligned.

