

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. 17-362, 17-371, 17-373, 17-374, 174-375, & 17-376
NON-HEATED GRIPS

ITEMS NEEDED: KNIFE SANDPAPER GRIP GLUE CLEANING SOLVENT

1. REMOVE HANDLEBAR WEIGHTS, IF APPLICABLE.
2. REMOVE BOTH GRIPS BY EITHER CUTTING THEM OFF OR TWISTING THEM OFF. SOME BIKES WITHOUT WEIGHTS HAVE CHROME CAPS THAT NEED TO BE SCREWED OR PRIED OFF.
3. CLEAN THE HANDLEBAR AND THROTTLE TUBE OF ANY REMAINING GLUE LEFT BEHIND FROM THE OLD GRIPS. WITH ALL THE GLUE REMOVED, LIGHTLY ROUGH THE SURFACE UP WITH SANDPAPER THEN CLEAN THE SURFACE WITH A MILD SOLVENT.
4. APPLY GRIP GLUE TO INSIDE OF GRIPS. A BEAD OF GLUE NEEDS TO BE PLACED AROUND THE ENTIRE INSIDE DIAMETER. AS THE GRIPS ARE SLID ONTO THE HANDLEBARS, IT WILL SPREAD THE GLUE ALONG THE LENGTH OF THE GRIP. DO NOT PLACE GRIP GLUE DIRECTLY ON THE HANDLEBAR, THE GRIP WILL PUSH IT TOWARDS THE SWITCH BOX AND CREATE A MESS.
5. INSTALL THE GRIPS ON THE BIKE AND REINSTALL HANDLEBAR WEIGHTS, IF APPLICABLE. MAKE SURE THE GRIP GLUE CURES FOR THE TIME SPECIFIED.