

# **BIG BIKE PARTS®**      **INSTALLATION INSTRUCTIONS**

PART NO. 17-379C

COMFORT WRIST CRUISE

FITS 17-371, 17-373, 17-374, 17-375, 17-381,  
17-383, 17-384, & 17-385 GRIPS

TOOLS NEEDED: 4MM ALLEN WRENCH

**NOTE: WE RECOMMEND USING A SMALL AMOUNT OF THREAD LOCKER ON ALL HARDWARE INSTALLED.**

1. REMOVE THE SMALL METAL CAP IN THE END OF THE GRIP BY CAREFULLY PRYING THE CAP OFF WITH SOMETHING THIN AND RIGID. USE SOMETHING SOFT LIKE PLASTIC SO THAT YOU DO NOT SCRATCH THE CHROME FINISH ON THE GRIPS.
2. INSTALL THE WRIST CRUISE BY INSERTING THE END WITH THE TEETH INTO THE OPENING IN THE END OF THE GRIP AND SECURE IT BY USING THE M6 SCREW SUPPLIED. ADJUST THE POSITION OF THE WRIST CRUISE SO IT WILL BE IN A COMFORTABLE POSITION FOR YOUR WRIST WHEN RIDING.

**NOTE: YOU MAY NEED TO GO FOR A TEST RIDE WITH THE WRIST CRUISE INSTALLED TO ENSURE THAT IT IS POSITIONED TO BEST SUIT YOU BEFORE APPLYING THE THREAD LOCKER.**

**NOTE: IF YOU ARE INSTALLING THE GRIPS AT THE SAME TIME, INSTALL THE GRIPS AND ALLOW GRIP GLUE CURE BEFORE INSTALLING THE WRIST CRUISE.**