

CHROME KNOB INSTALLATION TIPS

WE HAVE FOUND THAT SOME CHROME KNOBS HAVE GOTTEN THROUGH OUR RIGID QUALITY STANDARDS AND MAY BE A LITTLE DIFFICULT TO INSTALL ON YOUR BIKE. IF YOU ARE EXPERIENCING DIFFICULTY, TRY ONE OF THE THREE SUGGESTIONS BELOW:

1. APPLY MORE PRESSURE WHEN TRYING TO INSTALL THE KNOBS OVER THE SPINDLE.
2. TRY TO ROUND OUT THE METAL CLIP IN THE INSERT OF THE KNOB ON THE CURVED SIDE, WHICH IS CAUSING THE KNOB TO INSTALL HARD.
3. YOU MAY REMOVE THE METAL CLIP PROVIDED AND EXCHANGE IT WITH THE METAL CLIP FROM THE KNOBS BEING REPLACED.

WE ARE SORRY FOR ANY INCONVENIENCE THIS MAY CAUSE YOU.