BIG BIKE PARTS INSTALLATION INSTRUCTIONS

CHROME MIRROR MOUNT COVERS PART NO. 2-493

FITS ALL GL1500/6 GOLD WING MODELS

TOOLS REQUIRED: #2 PHILLIPS SCREWDRIVER

INSTALLATION:

- 1. PLACE YOUR GOLD WING SECURELY ON ITS CENTER STAND
- 2. UNHOOK THE L/R RUBBER MIRROR GASKETS (1A) FROM THE MIRRORS (1B) AND MIRROR MOUNT COVERS (1C).
- 3. RELEASE THE L/R MIRROR COVER SPRING CLAMP (1D) FROM THE FAIRING LEDGE (1E) AND PIVOT THE MIRROR MOUNT COVERS (1C) SO AS TO EXPOSE THE THREE SCREWS (1F).
- 4. USING THE #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE THREE L/R SCREWS (1F) HOLDING THE MIRROR UNIT MOUNTING BRACKET IN PLACE.

<u>NOTE:</u> PIVOTING THE MIRROR UNIT (1B) BACK AND OUT OF THE WAY MAY GIVE BETTER ACCESS TO ALL SCREWS, BUT <u>DO NOT</u> PIVOT MIRROR UNIT IF ANY OF THE SCREWS HAVE ALREADY BEEN REMOVED AS THIS COULD PUT UNEVEN PRESSURE ON A SCREW MOUNTING HOLE THAT COULD CAUSE DAMAGE.

- 5. NOW WITH THE MIRROR UNITS DETACHED, USE THE #2 PHILLIPS SCREWDRIVER TO REMOVE THE SPRING CLAMP (1D) FROM THE L/R OEM MIRROR MOUNT COVERS.
- 6. USING THE EXISTING SPRING CLAMP SCREWS REMOUNT THE OEM SPRING CLAMP ONTO THE NEW CHROME MIRROR MOUNT COVERS
- 7. REINSTALL THE MIRROR MOUNT COVER AND MIRRORS FOLLOWING INSTRUCTIONS 1 TO 4 ABOVE, IN REVERSE ORDER.

CARE: CLEAN ONLY WITH SOAP AND WATER, DO NOT USE ANY ABRASIVE CLEANERS.

