

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART# 20-100 CLASSIC WINDSHIELD TRIM KIT
BBP CLASSIC WINDSHIELDS &
SLIPSTREAMER CLASSIC & FALCON

ITEMS REQUIRED: 4MM ALLEN WRENCH
8MM WRENCH
11 MM WRENCH

INSTALLATION:

1. CAREFULLY REMOVE THE WINDSHIELD FROM THE BIKE, BY REMOVING THE (6) 8MM ALLEN HEAD BOLTS AND NUTS ON THE FORK CLAMPS
2. PLACE THE WINDSHIELD ON A TOWEL OR SOFT SURFACE TO PROTECT IT WHILE REPLACING THE TRIM.
3. REMOVE THE EXISTING TRIM & HARDWARE FROM THE WINDSHIELD & SET ASIDE. (NOT TO BE RE-USED)
4. INSERT TEE BOLTS INTO NEW TRIM AS SHOWN IN FIG "A". POSITION THEM TO MATCH HOLES IN WINDSHIELD & INSTALL USING THE FLAT WASHERS & ACORN NUTS SUPPLIED. (**CAUTION: DO NOT OVER TIGHTEN THIS COULD CAUSE A BREAK**)
5. RE-INSTALL ONTO BIKE BY REVERSING STEP ONE.

