

# BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

## PART NO. 20-4 WINDSHIELD GL 1500

ITEMS REQUIRED: MASKING TAPE #2 PHILLIPS SCREWDRIVER

### INSTALLATION:

1. TAKE THE VENT AND REMOVE THE TWO PHILLIPS SCREWS HOLDING THE FRONT AND BACK VENT PIECES TOGETHER. SEE FIG. 1X.
2. INSTALL THE VENT IN THE NEW WINDSHIELD BY INSERTING THE FRONT HALF INTO THE CUTOUT ON THE WINDSHIELD (MAY HAVE TO FLEX WINDSHIELD SLIGHTLY TO GET VENT INSERTED. DO NOT OVER FLEX WINDSHIELD OR IT WILL BREAK).
3. THEN INSTALL THE REAR HALF BY INSERTING THE TOP FIRST AND THEN SNAPPING THE BOTTOM TOGETHER.
4. INSTALL BOTH PHILLIPS SCREWS AND TIGHTEN
5. UNHOOK THE L/R RUBBER MIRROR GASKETS (1A) FROM THE MIRRORS (1B) AND MIRROR COVERS (1C).
6. RELEASE THE L/R MIRROR COVER SPRING CLAMPS (2A) FROM THE FAIRING LEDGE (2B) AND PIVOT THE MIRROR COVERS (2C) SO AS TO EXPOSE SCREWS (4A) HOLDING THE TRIM HOLDER WINDSHIELD PANEL (4B).
7. PIVOT THE MIRRORS (1B) BACK AND OUT OF THE WAY. USING A #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE L/R SCREWS HOLDING THE TRIM HOLDER.
8. GRASP THE WINDSHIELD PANEL (4B) AND PULL IT FORWARD TO DISENGAGE THE TWO TABS (4C) JUST ABOVE THE HEADLIGHT (4D).
9. USING A #2 MEDIUM PHILLIPS SCREWDRIVER, REMOVE THE FIVE SCREWS (5A) HOLDING THE WINDSHIELD (5B) & REMOVE THE WINDSHIELD.
10. REPLACE WINDSHIELD AND ALL OTHER COMPONENTS BY REVERSING STEPS 1 THROUGH 5.

