

## INSTALLATION INSTRUCTIONS

REPLACEMENT FOR HONDA  
FLOORBOARDS VTX 1300 RETRO  
PART NO. 21-554 VTX 1800 RETRO

TOOLS NEEDED: NEEDLE NOSE PLIERS

1. USING A NEEDLE NOSE PLIERS, REMOVE THE CLIP ON THE PIN HOLDING THE OEM BOARD ON.
2. TAKE OUT THE PIN CAREFULLY NOTING HOW THE SPRING FITS IN.
3. INSTALL THE NEW BOARD RE-USING THE SPRING, PIN AND CLIP.