

# **BIG BIKE PARTS®** INSTALLATION INSTRUCTIONS

TWISTED CRUISER  
MIRRORS  
PART NO. 28-601 & 28-602

10MM REVERSE  
MOUNT FOR  
YAMAHA  
CRUISER

TOOLS REQUIRED: 17MM WRENCH, 2MM ALLEN WRENCH, 13MM SOCKET

**NOTE: THE RIGHT SIDE MIRROR IS A LEFT HAND THREAD. THE NUTS WILL HAVE TO BE TURNED IN THE OPPOSITE DIRECTION OF THE LEFT SIDE.**

## INSTALLATION:

1. USING THE 17MM WRENCH LOOSEN THE NUT THAT HOLDS THE MIRRORS ON. SPIN THE WHOLE MIRROR ASSEMBLY TO TAKE IT OFF.
2. THREAD THE NEW MIRRORS INTO THE BIKE. DO NOT TIGHTEN.
3. POSITION THE MIRRORS INTO THE DESIRED POSITION FOR VIEWING COMFORT.
4. ONCE MIRRORS ARE IN THE DESIRED POSITION, TIGHTEN THE 17MM NUT THAT HOLDS THE MIRROR STEMS IN PLACE.
5. TO TIGHTEN MIRROR HEAD USE A 2MM ALLEN WRENCH TO REMOVE THE 2 SCREWS HOLDING THE MIRROR HEAD TO THE MIRROR STEM.
6. USING A 13MM SOCKET SLIGHTLY TIGHTEN THE NUT ON THE END OF THE MIRROR STEM AND REASSEMBLE MIRROR HEAD.

NOTE: WE RECOMMEND USING REMOVABLE THREAD LOCK COMPOUND ON ALL THREADS.