

Copyright © 2020 by Big Bike Parts, Inc. No part of this instruction sheet may be reproduced without the written permission of Big Bike Parts, Inc.

PART NO. 41-182/41-182BK/41-182E

KEY COVER

FITMENT: CAN-AM SPYDER, 2008-NEWER

3/26/2020

TOOLS NEEDED: SUPER GLUE

PAPER TOWEL

PLEASE READ THROUGH AND UNDERSTAND THESE INSTRUCTIONS BEFORE BEGINNING.
ESTIMATED INSTALLATION TIME: 5 TO 10 MIN.

WARNING

KEEP THE NUMBER OF KEYS AND FOBS TO A MINIMUM ON THIS KEY RING. EXCESSIVE WEIGHT MAY CAUSE DAMAGE TO IGNITION.

INSTALLATION:

4. SEPARATE THE TWO HALVES OF THE KEY COVER AND LAY THEM ON A CLEAN PAPER TOWEL.
5. APPLY FOUR SMALL DROPS OF SUPER GLUE TO THE INSIDE OF THE FRONT HALF AS SHOWN IN FIG. 1. (**NOTE: THE FRONT IS THE THINNER HALF**)
6. SNAP THE FRONT AND BACK TOGETHER WITH THE KEY AS SHOWN IN FIG. 2.

4 DROPS OF SUPER GLUE



FRONT
(THIN)

FIG. 1



BACK
(THICK)



FRONT

BACK

FIG. 2

ALWAYS GRIP THE KEY WHEN OPENING SEAT AND TRUNK

