

BIG BIKE PARTS®

LOWER AIR VENTS
PART NO. 52-552

INSTALLATION INSTRUCTIONS

FOR GOLDWING
1988-2000

TOOLS REQUIRED: (2) FLAT BLADE SCREWDRIVERS

1. TO REMOVE THE EXISTING (OEM) AIR VENT, USE THE SCREWDRIVERS TO PUSH UP ON THE (2) KEEPER TABS (LOCATED ON THE INSIDE LOWER FLANGE). THEN USE A SCREWDRIVER TO PRY BEHIND THE EDGE OF THE VENT.
2. INSTALL NEW VENTS BY PUSHING THEM INTO PLACE UNTIL FLUSH WITH PANEL.

Check out the collection of custom motorcycle accessories and trim we offer.