

ITEMS REQUIRED: PHILLIPS SCREWDRIVER

INSTALLATION:

1. REMOVE THE TWO SCREWS (1A) THAT HOLD THE RIGHT SIDE TRUNK MOLDING (1B) ON.
2. REMOVE THE TWO SCREWS (1C) THAT HOLD THE LEFT SIDE TRUNK MOLDING (1D) ON.
3. REMOVE THE TWO SCREWS (1E) THAT HOLD THE CENTER TRUNK MOLDING (1F) ON.
4. INSTALL THE NEW CHROME MOLDING IN THE REVERSE OF REMOVAL.

