

## INSTALLATION INSTRUCTIONS

Chrome Passenger Floor Fits GL1800 GoldWing  
Board Side Covers

Part No. 52-613

ITEMS REQUIRED: 5MM ALLEN WRENCH

1. REMOVE SIDE COVERS.
2. REMOVE SOCKET HEAD BOLTS (1A) HOLDING COVER ON USING 5MM ALLEN WRENCH (BOTH SIDES).
3. REMOVE THE RUBBER GROMMET (1B) FROM COVER AND PUT IT INTO NEW COVER (BOTH SIDES).
4. INSTALL NEW COVER USING OEM SOCKET HEAD BOLTS REMOVED IN STEP 2 (BOTH SIDES).
5. BE SURE NOT TO SCRATCH PART DURING INSTALL. WHEN FASTENING NEW SIDE COVERS, INSTALL TWO FORWARD SCREWS FIRST BUT DO NOT TIGHTEN ALL THE WAY. INSERT THE REAR SCREW, YOU MAY HAVE TO BEND THE PART SLIGHTLY TO GET THE SCREW STARTED.
6. TIGHTEN ALL FASTENERS.

