

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS
CHROME ABS FITS GL1800 GOLDWING
LOWER VENTS
PART NO. 52-642

TOOLS REQUIRED: FLAT BLADE SCREWDRIVER

INSTALLATION:

1. CAREFULLY PRY ON THE SIDES OF THE OLD AIR VENT TO SNAP IT OUT.
2. INSTALL THE NEW AIR VENTS BY SNAPPING IT INTO THE OPENING.