

BIG BIKE PARTS® INSTALLATION INSTRUCTIONS

PART NO. 52-677A

GL1800 ARMREST

TOOLS NEEDED: PHILLIPS SCREWDRIVER 6MM ALLEN WRENCH (BALL END WORKS BEST) 10MM WRENCH

NOTE: IF YOU HAVE THE HONDALINE PASSENGER AUDIO CONTROLLER MOUNTED TO THE RIGHT SIDE POCKET, YOU WILL NEED TO RELOCATE IT TO THE LEFT SIDE POCKET. THE KNOB AND BUTTON SIDE NEEDS TO BE POINTING OUTWARD AND THE LONG RUBBER END GOES ON THE FRONT OF THE POCKET.

1. USING THE 6 MM ALLEN WRENCH, REMOVE THE BOLTS (1A) HOLDING THE PASSENGER HANDRAILS (1B) TO THE SEAT (1C). REMOVE THE HANDRAILS (1B) ON BOTH SIDES.
2. ATTACH THE MOUNTING BRACKET (2A) TO THE BIKE BETWEEN THE PASSENGER HANDRAILS (1B) AND THE SEAT (1C). PLACE THE FOAM DISCS (1D) BETWEEN THE HANDRAIL (1B) AND THE MOUNTING BRACKET (2A). USE THE LONGER BOLTS PROVIDED AND TIGHTEN COMPLETELY.

NOTE: IF YOU ARE USING BIG BIKE PARTS® BACKREST, THEN THE ARMREST MOUNTING BRACKET (2A) WILL GO AGAINST THE SEAT (1C), THEN THE BACKREST MOUNTING BRACKET, AND THEN THE HANDRAIL (1B).

3. ATTACH THE ARMREST PAD (2F) TO THE ARMREST (2B) USING THE ¼-20 X ¾" PHILLIPS SCREWS (2G) AND THE FLAT WASHERS (2H) AND TIGHTEN. DO THIS FOR BOTH SIDES.
4. INSTALL THE ARMREST (2B) ONTO THE MOUNTING BRACKET (2A) USING THE M6-1.0 X 75 MM CARRIAGE BOLT (2C), PLASTIC WASHERS (2D), AND NYLOC NUT (2E). THE CARRIAGE BOLT (2C) SHOULD BE SNUG ENOUGH TO HOLD THE ARMREST IN POSITION DURING USE BUT ALLOW THE ARMREST TO "SWING AWAY" FOR PASSENGER ACCESS.

NOTE: TO AVOID BREAKING THE PLASTIC WASHERS, DO NOT OVER TIGHTEN THE NYLOC NUT.

CAUTION: THE ARMRESTS ARE DESIGNED FOR RESTING OF THE ARMS NOT AS A SUPPORT TO LEAN ON OR PUSH ON TO GET ON OR OFF THE BIKE.

