

# **BIG BIKE PARTS™** INSTALLATION INSTRUCTIONS

MIRROR TRIM  
PART NO. 52-683

HONDA GL1800  
GOLD WING

ITEMS REQUIRED: RUBBING ALCOHOL

## INSTRUCTIONS:

1. CLEAN THE EDGE OF MIRROR HOUSING WITH RUBBING ALCOHOL.
2. PLACE THE TAPE ON THE EDGE OF THE MIRROR HOUSING AND PEEL THE BACKING OFF.
3. STICK THE MIRROR TRIM TO THE MIRROR HOUSING AND PRESS FIRMLY FOR 30 SECONDS.
4. DO THE SAME FOR THE OTHER SIDE.

**NOTE:** THE DOUBLE SIDED TAPE IS NOT ATTACHED TO THE PART. IT IS BETTER TO PLACE THE TAPE ON THE MIRROR HOUSING AND THEN ATTACH MIRROR TRIM TO HOUSING.

Check out the collection of custom motorcycle accessories and trim we offer.