

BIG BIKE PARTS

INSTALLATION INSTRUCTIONS

CHROME UPPER AIR VENTS HONDA
PART NO. 52-684 GL1800

TOOLS REQUIRED: FLAT BLADE SCREWDRIVER

1. REMOVE THE OLD AIR VENT BY PRYING DOWN ON THE TWO TABS THAT ARE ON THE INSIDE LIP AND PRY THE VENT OUT.
2. INSTALL THE NEW AIR VENT BY PUSHING IT INTO PLACE.