

INSTALLATION INSTRUCTIONS

CLEAR TURNSIGNAL LIGHT HONDA GL1800 GOLDWING

PART NO. 52-733

TOOLS NEEDED: PHILLIPS SCREWDRIVER
T15 TORX SCREWDRIVER

INSTALLATION:

1. USING PHILLIPS SCREWDRIVER, REMOVE THE PHILLIPS SCREW ON BOTTOM OF MIRROR HOUSING AND REMOVE THE MIRROR.
2. USING T15 TORX SCREWDRIVER, REMOVE THE THREE TORX SCREWS HOLDING THE MIRROR FRAME TO MIRROR HOUSING.
3. REMOVE THE LIGHT BULB SOCKET FROM THE LIGHT HOUSING AND PULL THE LIGHT HOUSING OUT OF MIRROR HOUSING.
4. REMOVE THE CLEAR STOCK BULB FROM THE LIGHT BULB SOCKET AND INSTALL THE NEW AMBER BULB PROVIDED.
5. PLUG THE LIGHT BULB SOCKET INTO THE NEW CLEAR LIGHT HOUSING AND INSTALL LIGHT HOUSING INTO MIRROR HOUSING IN THE REVERSE OF REMOVAL.