

# INSTALLATION INSTRUCTIONS

## FOR ADHESIVE CHROME ACCESSORIES

### INSTALLATION:

1. **CHECK** – CHECK FITMENT OF PART SO YOU KNOW HOW IT GOES ON.
2. **CLEANLINESS** – USE A MILD SOLVENT, SUCH AS RUBBING ALCOHOL, APPLIED WITH A CLEAN, LINT FREE RAG TO PREPARE THE SURFACE.
3. **APPLICATION** – THERE IS ONLY ONE CHANCE TO INSTALL. LIFT ONE EDGE OF THE PROTECTIVE BACKING ENOUGH SO YOU CAN PEEL IT AWAY IF YOU HOLD THE PART IN POSITION. GENTLY POSITION THE ACCESSORY IN PLACE AND SLOWLY PEEL THE PROTECTIVE BACKING OFF WHILE ADHERING THE ACCESSORY IN PLACE. APPLY PRESSURE TO THE WHOLE PART FOR 30 SECONDS. PUSH FIRMLY IN PLACE.
4. **MAINTENANCE** – THE ADHESIVE SHOULD BE ALLOWED TO SET FOR 72 HOURS BEFORE EXPOSURE TO RAIN OR WASHING. AFTER THE ADHESIVE SETS YOU CAN APPLY CHROME POLISH OR WAX TO THE ACCESSORY. PROPER PROTECTION FROM DAILY MOISTURE, SUCH AS DEW OR RAIN, WILL INCREASE THE LIFE OF ALL CHROME ACCESSORIES.